


INSTRUCTIONS FOR USING MULTI-PURE CARTRIDGE IN OGDEN MODEL "A" HOUSING



1. Shut off water to purifier. Open outlet water faucet to relieve pressure.
2. Remove wingnut, cover and used cartridge.
3. *Remove and discard both Ogden upper and lower seals.
4. Clean inside and rinse.
5. Insert the Multi-Pure black rubber lower seal**. Insert the Multi-Pure cartridge and the white rubber upper seal (washer)
6. Turn on water and allow unit to fill.
7. Replace wing nut and cover.
8. Tighten wingnut **FIRMLY** by **HAND**.
9. Turn on water supply, open faucet and allow to waste for 3 minutes.

**This lower seal only requires periodic replacement. (Between 1-2 yrs. or every 2-4 cartridge replacements.)

The OGDEN Water Purifier



MODEL
ALT

A proven system of drinking water protection in use throughout the world since 1950.

PARTS LIST

METAL REPLACEMENT PARTS

LIST PRICES

25-101-2 P	Polished Stainless Steel Body	33.20
25-102-1 P	Cover, Polished Stainless Steel	8.25
25-103-1	Wingnut With Gasket, Chrome Plated	3.40
25-150	Ogden Stainless Steel Outlet Faucet	8.95
25-20	Outlet Faucet Elbow, Chrome Plated	1.25
25-120 TS	Mounting Assembly, Stainless Steel	15.20
25-120-1	Mounting Flange, Stainless Steel	5.40
25-120-2	Mounting Stud, Stainless Steel	7.60
25-120-3	Rubber Mounting Flange Gasket	.23
25-120-4	Lock Nut, Special Thread For Stud	.97
25-120-7	Extra-Large Above Sink Washer - 1 7/8"	1.40
25-120-8	Undersink Washer, Plated - 1 7/8" O. D.	.70
25-9	Tubing Nut (1/4"), Special Thread	.30
25-10 P	Tubing Sleeve (1/4") Plastic	.04

RUBBER REPLACEMENT PARTS

25-50-2	Cover Gasket - "O" Ring	.68
25-11	Wingnut Gasket - "O" Ring	.25
25-104-3 L	Lower Seal (In bottom of Unit)	.95
25-104-3	Upper Seal (Inside of Cover)	.95
25-150-1	Washer For Ogden Stainless Steel Faucet	.06
25-RA-1	Complete Rubber Replacement Kit	2.80

INSTALLATION ACCESSORY KIT - All necessary parts 3.20

REPLACEMENT CARTRIDGES (Any of the following...) 4.45

Type	Particle Retention	Approximate Capacity*	Recommended Uses...
LPI-1 (Yellow end washers)	5 microns	1000 gallons	FILTER & PURIFY Removes: chlorine, iodine, algae, dirt, rust, scale, organic tastes, colors, odors, detergents, radioactive solids, iron and some hydrogen sulfide.
LPI-7 (Blue end washers)	2 microns	500 gallons	
SM1 + (Green end washers)	0.4 microns	200 gallons	FILTER PURIFY & DISINFECT Removes: all of the above plus intestinal-type disease producing bacteria and amoebic cysts. SM1 should be used for highly contaminated water.
SH1 (Black end washers)	0.2 microns	150 gallons	

* Based on a constant pressure of 50 p. s. i. and turbidity of 1.0 p. p. m.
+ Standard with all new units.

NOTE: All of the above cartridges are self-sanitizing in use and will not allow the growth and reproduction of harmful bacteria.